

# WET LOCKER, BATTERY BOX, DOOR 3,4 5 & 6 LOCK ASSEMBLY

Looking at picture A  
make sure you have all  
the components, 1  
Barrel housing, 1 grey  
pawl, 1 white pawl, 2  
standard springs and 1  
conical spring.

Picture B illustrates  
the lock housing.



Firstly insert the grey  
lock pawl so the catch  
part is facing to  
towards the outer edge  
of the door as shown  
in picture C

Secondly position the  
lock housing between  
the two grooves as seen  
in picture D



Using image E position the white lock pawl so the teeth engage with those on the grey pawl and the arms straddle the barrel housing.

In picture F you can see where the 2 standard springs sit between the white pawl and the outer casing of the door



Picture G shows the conical spring sitting on top of the barrel housing. Once this is done place the cover back over the lock mechanism and screw down using the screws provided

