

Toilet Part #'s by Discription	OEM	Distrib.	Tray	CP*
Aria Deluxe				*Consumer Packaging
Aria Deluxe- High, White	19425			19596
Aria Deluxe- High, Bone	19692			19694
Aria Deluxe- Low, White	19430			19597
Aria Deluxe- Low, Bone	19693			19695
Aria Deluxe II				
Aria Deluxe II- High, White	19767	19766	19425	19766
Aria Deluxe II- High, Bone	19768	19764		19764
Aria Deluxe II- Low, White	19765	19771		19771
Aria Deluxe II- Low, Bone	19770	19769		19769
Aria Classic				
Aria Classic- High, White	19802	19800		19800
Aria Classic- High, White W/S	19806	19799		19799
Aria Classic- High, Bone	19804	19801		19801
Aria Classic- High, Bone W/S	19808	19798		19798
Aria Classic- Low, White	19803	19818		19818
Aria Classic- Low, White W/S	19807	19825		19825
Aria Classic- Low, Bone	19805	19822		19822
Aria Classic- Low, Bone W/S	19809	19819		19819
Aqua Magic- Style II				
Style II- High, White	42050	42058	42070	42058
Style II- High, White W/S	42052	42060	42074	42060
Style II- High, White w/Pedal Cover	42104	42117		42117
Style II- High, White w/Pedal Cover W/S	42105	42118		42118
Style II- High, Bone	42054	42062	42072	42062
Style II- High, Bone W/S	42056	42064	42076	42064
Style II- High, Bone w/ Pedal Cover	42106	42119		42119
Style II- High, Bone w/ Pedal Cover W/S	42107			42120
Style II- Low, White	42051	42059	42071	42059
Style II- Low, White W/S	42053	42061	42075	42061
Style II- Low, Bone	42055	42063	42073	42063
Style II- Low, Bone W/S	42057	42065	42077	42065
Aqua Magic- Style Lite				
Style Lite- High, White	34060	34068		34068
Style Lite- High, White W/S	34061	34070		34070
Style Lite- High, Bone	34064	34069		34069
Style Lite- High, Bone W/S	34065	34074		34074
Style Lite- Low, White	34062	34071		34071
Style Lite- Low, White W/S	34063	34073		34073
Style Lite- Low, Bone	34066	34075		34075
Style Lite- Low, Bone W/S	34067	34076		34076
Aqua Magic- Style Plus				
Style Plus- High, White	34420	34429		34429
Style Plus- High, White W/S	34421	34431		34431

Style Plus- High, Bone	34424	34430		34430
Style Plus- High, Bone W/S	34425	34435		34435
Style Plus- High, Black	34440	34442		34442
Style Plus- High, Black W/S	34441	34443		34443
Style Plus- Low, White	34422	34433		34433
Style Plus- Low, White W/S	34423	34434		34434
Style Plus- Low, Bone	34427	34438		34438
Style Plus- Low, Bone W/S	34428	34439		34439
Style Plus- Low, Black W/S	34445			

Aqua Magic- Bravura

Bravura- High, White	31082	31084		31084
Bravura- High, White W/S	31104	31100		31100
Bravura- High, Parchment	31083	31085		31085
Bravura- High, Parchment W/S	31105	31101		31101
Bravura- Low, White	31120	31120		31086
Bravura- Low, White W/S	31122	31122		31102
Bravura- Low, Parchment	31119	31119		31087
Bravura- Low, Parchment W/S	31121	31121		31103

Aqua Magic- IV Foot Flush

AM IV- High, White	24820	24820	24976	28770
AM IV- High, Parchment		28502		28502
AM IV- Low, White	24810	24810		
AM IV- Low, Parchment	20810	20810		

Aqua Magic- IV Hand Flush

AM IV- High, White	24920	24920	24973	28769
AM IV- High, Parchment	28505	28505		
AM IV- Low, White	24919	24919		
AM IV- Low, Parchment	20919	20919	24974	

Aqua Magic- V Hand Flush

AM V- High, White	31648	31667	31683	31667
AM V- High, White W/S	31659	31675	31691	31675
AM V- High, Parchment	31649	31668	31684	31668
AM V- High, Parchment W/S	31660	31676	31692	31676
AM V- Low, White	31646	31646	31681	31646
AM V- Low, White W/S	31657	31647	31689	31657
AM V- Low, Parchment	31647	31647	31682	31647
AM V- Low, Parchment W/S	31658	31658	31690	31658

Aqua Magic- V Foot Flush

AM V- High, White	31652	31671	31687	31671
AM V- High, White W/S	31663	31679	31695	31679
AM V- High, Parchment	31653	31672	31688	31672
AM V- High, Parchment W/S	31664	31680	31696	31680
AM V- Low, White	31650	31650	31685	31650
AM V- Low, White W/S	31661	31661	31693	31661
AM V- Low, Parchment	31651	31651	31686	31651
AM V- Low, Parchment W/S	31662	31662	31694	31662

Aqua Magic- Galaxy & Starlite

Galaxy Starlite- GH, White W/S, tan pad		24911		24911
Galaxy Starlite- GH, Parchment, tan pad		24995		24995
Galaxy Starlite- GH, Parchment W/S, tan pad		20911		20911
Galaxy Starlite- GL, White W/S, tan pad		24907		24907
Galaxy Starlite- GL, Parchment W/S, tan pad		20907		20907
Galaxy Starlite- SH, White		24902		24902
Galaxy Starlite- SL, White		24900		24900
Galaxy Starlite- SL, White W/S		24901		24901
Galaxy Starlite- SL, Parchment		20900		20900

Aqua Magic- Aurora

Aurora- White	19229			19231
Aurora- Bone	19249			19251
Aurora- White W/S	19230			19232
Aurora- Bone W/S	19250			19252

Aqua Magic- Residence

Residence- High, White	42161	42169	42153	42169
Residence- High, White W/S	42165	42173	42157	42173
Residence- High, Bone	42163	42171	42155	42171
Residence- High, Bone W/S	42167	42175	42159	42175
Residence- Low, White	42162	42170	42154	42170
Residence- Low, White W/S	42166	42174	42158	42174
Residence- Low, Bone	42164	42156	42156	42172
Residence- Low, Bone W/S	42168	42176	42160	42176

Electra Magic Model 80

Electra Magic- RV, 12 Volt		24345		24345
Electra Magic- Marine, 24 Volts		24344		34344

Tecma- ComfortMate

ComfortMate- Manual, White		41160		41160
ComfortMate- Electric, White		41211		41211

Tecma- EasyFit

Efit- High, White, 12volt	38508			
Efit- High, White, 24volt	38509			
Efit- High, Bone, 12volt	38512			
Efit- High, Bone, 24volt	38513			
Efit- Low, White, 12volt	38510			
Efit- Low, White, 24volt	38511			
Efit- Low, Bone, 12volt	38514			
Efit- Low, Bone, 24volt	38515			
Efit Premium Plus- Low, White, 12volt	38832			

Tecma- Compass

Compass Eco- White, 12volt				38990
Compass Eco- White, 24volt				38991
Compass Premium Plus- White, 12volt				38992
Compass Premium Plus- White, 24volt				38993

Tecma- E-Breeze

E-Breeze- White, 24volt, [230VAC] 2 Buttons				38975
E-Breeze- White, 24volt, [230VAC] Prem-touch				38976
E-Breeze- White, 24volt, [110VAC] 2 Buttons				98089
E-Breeze- White, 24volt, [110VAC] Prem-touch				98088

Tecma- Nano

Nano Eco- White, 12volt				38970
Nano Eco- White, 24volt				38971
Nano Premium Plus- White, 12volt				38972
Nano Premium Plus- White, 24volt				38973

Tecma- Silence Plus

Silence Plus- High, White, DB- ES, 12volt	38101			38101
Silence Plus- High, White, DB- WP, 12volt	38119			38119
Silence Plus- High, White, DB- ES, 24volt	38111			38111
Silence Plus- High, Bone, DB- ES, 12volt	38102			38102
Silence Plus- High, Bone, DB- WP, 12volt	38120			38120
Silence Plus- High, Bone, DB- ES, 24volt	38112			38112
Silence Plus- Low, White, DB- ES, 12volt	38355			38355
Silence Plus- Low, White, DB- WP, 12volt	38363			38363
Silence Plus- Low, White, DB-ES, 24volt	38359			38359
Silence Plus- Low, Bone, DB- ES, 12volt	38356			38356
Silence Plus- Low, Bone, DB- WP, 12volt	38364			38364
Silence Plus- Low, Bone, DB- ES, 24volt	38360			38360
Silence Plus- High, Black, SB- ES, 12volt	38006			38006
Silence Plus- High, Black, SB- WP, 12volt	38429			38429
Silence Plus- High, White, SB- ES, 12volt				38024
Silence Plus- High, White, SB- ES, 24volt				38034
Silence Plus- Low, White, SB- ES, 12volt				38357
Silence Plus- Low, White, SB- ES, 24volt				38361

Tecma- Silence Plus (continued...)

Silence Plus- High, White Chrome, 12volt		38457		38457
Silence Plus- High, Bone Chrome, 12volt		38456		38456
Silence Plus- High, Black Chrome, 12volt		38458		38458
Silence Plus- High, Bone Gold, 12volt		38472		38472
Silence Plus- High, Black Gold, 12volt		38461		38461
Silence Plus- High, White Chrome, 24volt [M]		38660		38660
Silence Plus- High, Bone Chrome, 24volt [M]		38640		38640
Silence Plus- High, Black, 24volt [M]				38665
Silence Plus- Low, White Chrome, 12volt		38460		38460
Silence Plus- Low, Bone Chrome, 12volt				38459
Silence Plus- Low, Bone Gold, 12volt				38494
Silence Plus- Low, Bone, 12volt [M]				38664

Tecma- Silence

Silence- High, White, DB- WP, 12volt	38117			38117
Silence- High, White, DB- ES, 12volt				38097
Silence- High, White, DB- ES, 24volt	38107			38107

Silence- High, Bone, DB- WP, 12volt	38118			38118
Silence- High, Bone, DB- ES, 24volt	38108			38108
Silence- Low, White, DB- WP, 12volt	38121			38121
Silence- Low, White, DB- ES, 12volt	38103			38103
Silence- Low, White, DB- ES, 24volt	38113			38113
Silence- Low, Bone, DB- WP, 12volt	38122			38122
Silence- Low, Bone, DB- ES, 12volt	38104			38104
Silence- Low, Bone, DB- ES, 24volt	38114			38114
Silence- High-Bidet, White, DB- ES, 12volt	38099			38099
Silence- High-Bidet, White, DB- ES, 24volt	38109			38109
Silence- High-Bidet, Bone, DB- ES, 12volt	38100			38100
Silence- High-Bidet, Bone, DB- ES, 24volt	38110			38110
Silence- Low-Bidet, White, DB- ES, 12volt	38105			38105
Silence- Low-Bidet, Bone, DB- ES, 12volt	38116			38116
Silence- High, White, SB, ES, 12volt				38020
Silence- High, White, SB, ES, 24volt				38030
Silence- Low, White, SB, ES, 12volt				38026
Silence- Low, White, SB, ES, 24volt				38036
Silence- High, White Chrome, 24volt		38589		38589

Cassette- C2 Electric

C200- CS, Electric- Right Hand	2350562	1632362	1632262	2350562
C200- S, Electric- Remote Console				2350762
C200- CW Manual		2352157		2352157

Cassette- C4 Manual

C402- C, Manual- Right Hand		32811		32811
C402- C, Manual- Left Hand	1632362	32812		32812
C403, Manual- Right Hand		32813		32813
C403, Manual- Left Hand		32814		32814

Porta Potti

Porta Potti- 135		25100		25100
Porta Potti- 135 Marine	25102	25103		25103
Porta Potti- 155		24155		24155
Porta Potti- 235/245/255/265				24235
Porta Potti- 345		25113		25113
Porta Potti- 365		25112		25112
Porta Potti- 365 MSD		25109		25109
Porta Potti- 465E		25111		25111
Porta Potti- 465E MSD		25110		25110
Porta Potti- 555	73644			28528
Porta Potti- 565				28527
Porta Potti- 735 MSD		25105		25105
Porta Potti- 735 Marine				25104
Porta Potti- 735 MSD 90-Degree				25106
Porta Potti- 260B				92859
Porta Potti- 260B Marine				92862
Porta Potti- 260P Marine				92865

Porta Potti- 260P MSD				92868
Porta Potti- 260P MSD 90-Degree				92871
Porta Potti- 320P				92850
Porta Potti- 550P				92853
Porta Potti-550P MSD				92856
Porta Potti- 550E, Curve				92360
Porta Potti- Campa Potti MG				35564
Porta Potti- Campa Potti XG				25108
Porta Potti- Campa Potti MT				92874
Porta Potti- Campa Potti XT				92877

