



LE1455_SHB165XX-vertical


		Spare part number	Colours available
1	Glass lid	Refer to page 3	
2	Hinges set	SSPA0010	
2A	Lid Shut-off switch (x1)	SSPA0611	
3	Control knobs	Refer to page 3	
4	Ignition switch and wire harness set		
	Production date: < 16/03/15 (E074S...)	No longer available	
	Production date: ≥ 16/03/15 (E074S...)	SSPA0332	
5	Gas taps set		
	Production date: < 16/03/15 (E074S...)	SSPA0428	
	Production date: ≥ 16/03/15 (E074S...)	SSPA0426	
6	Spark electrodes set		
	Production date: < 16/03/15 (E074S...)	SSPA0310	
	Production date: ≥ 16/03/15 (E074S...)	SSPA0320	
7	Thermocouple		
	Production date: < 16/03/15 (E074S...)		
	Front	SSPA0675	
	Rear	SSPA0676	
	Production date: ≥ 16/03/15 (E074S...)		
	Front	SSPA0680 SSPA0683	
	Rear	SSPA0682 SSPA0687	
8	Spark generator	SSPA0302	
9	Worktop fixing kit	SSPA0021	
10	Bezel	SSPA0076	
11	Bump stop set	SSPA0040	
12	Burner assembly medium / semi-rapid		
	Production date: < 16/03/15 (E074S...)	SSPA0111	
	Production date: ≥ 16/03/15 (E074S...)	SSPA0110	
13	Pan support medium	SSPA0965	
14	Burner assembly large / rapid		
	Production date: < 16/03/15 (E074S...)	SSPA0120	
	Production date: ≥ 16/03/15 (E074S...)	SSPA0124	
15	Pan support large burner	SSPA0953	

~~xxxxxx~~ = not available anymore

Glass lid

Spare part number	Colours available	
SSPA0280	Smoked clear	
SSPA0201	Solid black	

Control knobs



Spare part number	SSPA0911	SSPA0920
Colours available	Matt Nickel (.MNK)	Black (.BK)
Set quantity	3	3

XXXXX = not available anymore