



LE1327\_SOV10XXX

		Spare part number	Spare part number	Colours available
1	Ignition switch	SSPA0380		
2	Light switch*	SSPA0590		
3	Oven tap	SSPA0452		
4	Knob (1x)	SSPA0938.BK		Black
5	Oven seal	SSPA0063		
6	Oven door (without handle/hinges)	SMAO4230.BK95X		Black
	Spare handle V cut bright nickel 390mm ctrs	SSPA1060		
	Spare hinges	SSPA0015		
7	Glass, inner door	SSPA0255		
8	Oven shelf	SSPA0983		
9	<del>Grill pan</del>	<del>SSPA0993</del>		
	Grill pan + trivet (no handle)	SSPA0992		
10	Oven burner			
	<i>Production date: &lt; 31-07-21 (E212Y...)</i>	SSPA0191		
	<i>Production date: ≥ 01-08-21 (E213Y...)</i>	SSPA0198		
11	Electrode oven			
12	Thermocouple oven	SSPA0622		
13	Spark generator	SSPA0305		
14	Oven lamp*	SSPA0560		

\* Only applicable for models with light inside