


# Cassette® C223 CS



| Key No. | Part No. | Description                             |
|---------|----------|-----------------------------------------|
| 1       | 20095062 | Seat and Cover                          |
| 2       | 16833    | Vacuum Breaker                          |
| 3       | 20095262 | Flush Tube and Nozzle                   |
| 4       | 23709    | Electric Valve, Hose Nut, and Hose Barb |
| 5       | 200956   | Level Indicator Lens                    |
| 6       | 200957*  | Level Indicator                         |
| 7       | 200962   | PCB                                     |
| 8       | 20097462 | Control Panel and Sticker               |
| 9       | 200975   | Seal Base Wall                          |

Not available

\* Limited Availability