
5
6
7
9
26
24
25
10
8
11
2
27
12
1
28
13
15
14
29
30
34
20
32
19
16
33
21
31
3
17
4
28
18
20
22
35
23
36
1
2


38
39
41
40

		Spare part number	Spare part number
1 2	Right upper hinge / left bottom hinge Left upper hinge / right bottom hinge		692647
3	Middle hinge (left)	692648	
4	Middle hinge (right)	692649	
5	Control housing	692807	
6	Control panel PCB	692630	
7	Dust cover	692799	
8	Display sticker	692809	
9 10 11	Light housing LED light Light cover		692779
12	Evaporator fan	692980	
13 14	Fan net Fan cover		692806
15 16	Thermistor Thermistor cover		692776
17 18	Door latch plate Winter lock support		692758
19	Shelf cabinet	692979	
20	Clip shelf large	692761	
21	Vegetable bin	692767	
22	Shelf freezer	692812	
23	Drawer freezer	692813	
24 25 26	Upper hinge shaft Upper hinge shaft spring Silicone blanking cap		692883
27 28	Cabinet Door Door deco panel		692814
29	Door Bin	692794	
30 31 32 33 34	Door cover Handle connection shaft Big handle spring Handle Small handle spring		692815
28 35	Freezer deco panel Freezer door		692818
36	Panel retainer	692819	
38	Condenser fan cover	691887	
39	Condenser fan	692633	
40	Drip cup	692810	
41	Control module	692981	
Not depicted	Fuse Power cord		692982

Note Identification Label

With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.