



		<b>Spare part number</b>	<b>Colours available</b>
1	Ignition switch	SSPA0383	
2	Oven/grill tap	SSPA0462	
3	Knob (1x)	SSPA0910.CR/BK	Chrome/Black
4	Oven seal	SSPA0062	
5	Cut out thermal (1x NO)	SSPA0517	
6	Cut out thermal (1x NC)	SSPA0518	
7	Oven door (without handle/hinges)	SMAO3435.BK99X	Black
8	Spare handle (Alps 60 Brushed Inox)	SSPA1068	
9	Spare hinges	SSPA1791	
10	Glass, inner door	SSPA0253	
11	Oven shelf	SSPA1300	
12	Grill pan	SSPA0993	
13	Oven burner	SSPA0198	
14	Electrode oven	SSPA0697	
15	Thermocouple grill/oven		
16	Spark generator	SSPA0302	
17	Grill burner	SSPA0188	
18	Electrode grill	SSPA0698	
15	Thermocouple grill/oven		
19	Fan	SSPA0522	