

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
LE1347_SOH15XX

		Spare part number	Spare part number
1	Pan holder adjustable	~~SSPA0958~~	
2	Pan support	SSPA0959	
3	Burner assy (medium)		
	Prod date: < 28-02-13 (E059P…)	SSPA0130	
	Prod date: ≥ 01-03-13 (E060P…)	SSPA0812	
4	Thermocouple		
	Production date: < 28-02-13 (E059P…)	~~SSPA0677~~	
	Production date: ≥ 01-03-2013 (≥ E060P…)	SSPA0680	
5	Fascia sticker	Not available	
6	Gas tap burner 1x		
	Prod date: < 28-02-13 (E059P…)	SSPA0432	
	Gas tap burner 2x		
	Prod date: ≥ 01-03-13 (E060P…)	SSPA0430	
7	Gas tap grill		
	Prod date: < 28-02-13 (E059P…)	SSPA0472	
	Prod date: ≥ 01-03-13 (E060P…)	SSPA0470	
8	Gas tap oven		
	Prod date: < 28-02-13 (E059P…)	Not available	
	Prod date: ≥ 01-03-13 (E060P…)	SSPA0450	
9	Control knobs	SSPA1206.BK	
10	~~Door seal~~	~~SSPA0065~~	
11	~~Glass, inner door~~	~~SSPA0258~~	
12	Oven door	~~SMAO0041.BKX (for SOH1500 /1505/1507)~~	~~SMAO0041. BK01X (for SOH1509)~~
13	Oven shelf	SSPA0987	
14	Baking tray and roasting dish set	SSPA0999	
15	Grill cradle	SSPA0957	
16	Grill pan		
	Full set, including trivet and handle	~~SSPA0993~~	
	Grill pan + trivet (no handle)	SSPA0992	
	Trivet only	SSPA0998	
17	Oven burner	Not available	
18	Door restraint bar	~~SSPA0097~~	
19	Thermocouple oven		
	Prod date: < 28-02-13 (E059P …)	SSPA0153	
	Prod date: ≥ 01-03-13 (E060P…)	SSPA0623	
20	Thermocouple grill		
	~~Prod date: < 28-02-13 (E059P…)~~	~~SSPA0637~~	
	Prod date: ≥ 01-03-13 (E060P…)	SSPA0635	
21	~~Grill burner~~	~~SSPA0184~~	

~~xxxxxxx~~ = not available anymore